


Couper l'alimentation principale avant installation Always turn off main power before installation







This product contains a light source of the energy effciency class E.

The LED light source and Control Gear in this product can be replaced by a professional



KSR Lighting Aftersales: 023 92 674343 E-mail: aftersales@ksrlighting.com Installation får endast utföras av behörig elinstallatör.
Installation should be carried out by your local electrician.
Die Installation durch einen Fachmann vornehmen lassen.
L'installation doit être effectuée par un installateur qualifié.
We raden aan om de installatie door enn erkend vakman te laten doen.
Debe ser instalado por un electricista cualificado.
L'installazione deve essere effettuata da un elettricista qualificato.
Asennuksen saa tehdä vain pätevä sähköasentaja.

KSR Lighting Optimum House, Beeding Close, Southern Cross Trading Estate, Bognor Regis, West Sussex. PO22 9TS