Installation Sheet KSRFRD385

installation to retain for future reference/maintainence Read these instructions before commencing installation. Please give these instructions to the owner/occupier after

IP65 (🖶 💃 < € (]0.3m| № 240V~50Hz 5W/7W

These fittings are Class I and must be Earthed

Important Information

installation complies with current IEE wiring regulations & local building control. It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the

These products are designed for connection to a 240V~50Hz supply

Any faulty, broken or damaged luminaires should be replaced immediately

KSR will not accept responsibility for any claims arising from a poor installation

to workmanship in the installation of the products or parts. any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature (normal operating Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or ambient temperature -10 \sim +35°C), humidity conditions, fluctuations in the electrical system or physical abuse as well as failure related

Important User Advice

Always switch off mains supply before servicing.

ceilings This luminaire is suitable for indoor use only and should not be fitted to damp or wet surfaces such as freshly plastered or painted

2014/30/EU and should be disposed of in accordance with local legislation. damaged by high test voltages, they must be disconnected from the circuit before testing. To prevent damage to the driver, do not mix Do not use Megger or similar high voltage instruments. Due to the fact this luminaire contains electronic components that maybe with conventional magnetic ballasts on the same electrical circuit. At the end of life the luminaire is classed as WEEE under directive

Installation Procedure

KSR recommends that a sample hole is cut in some scrap material to familiarise yourself with the installation. Once you are completely

Locate the area's suitable to install these luminaires

loop in/loop out connections, if not looping through either of the L,E & N inputs can be used. Install the terminal cover/strain relief by Connect the mains supply to the connector block (Blue - Neutral, Yellow/Green - Earth and Brown - Live). The terminal allows mains Cut a 72mm round hole in the ceiling and ensure sufficient ceiling void without infringing on joists, water pipes or electrical cables pushing down until it grips the outer cable insulation.

Neutral White (4000K) or Cool White (6000K). Select the preferred colour temperature by sliding the selector switch to either Very Warm White (2700K), Warm White (3000K),

Proceed to Select the preferred Output via the Wattage Selector Switch either 5w or 7w

If you are installing one of the KSR detachable rims remove the standard white rim by pulling the trim off of the main fitting, do not twist This must be done before the luminaire is powered on. Press springs back and place luminaire body into aperture

the trim. Attach new trim by pushing and snapping it into place This downlight can be covered with mineral wool insulation

dimmers list over the page or visit www.ksrlighting.com for information on the latest compatible dimmers any other questions please way electronic LED drivers start up with higher inrush currents compared to halogen lighting. If dimming see the recommended *Please note: Depending on the amount of Qr fittings on a circuit you may have to upgrade the breaker to a 'C' or 'D' type due to the call our sales office

Installer Note:

strip back 10mm of insulation and push the cable firmly into the terminal block. To ensure a good connection






Qr Select II

4CCT Dual Wattage Downlight

Available finishes: White, Antique Brass, Brass, Copper, Black, Chrome, Satin Chrome or Stainless Steel

Part "C" Compliant

Stops moisture & air flow through the luminaire



2700K O 6000K 3000K 4000K	Colour Temperature Selector Switch
	WARNING: Do not change the CCT or Wattage of this downlight with the product switched on, all changes must be done with the power off.
WS WT	Wattage Selector Switch

795lm	635lm	6000K					
820lm	640lm	4000K					
760lm	590lm	3000K					
700lm	560lm	2700K	Yes	64 °	70mm	72mm	85mm
7W	5W		Dimmable	Angle	Required	Cut out	MIII OIZG
ut per head	Lumen output per head			Beam	Void Depth Beam	$\frac{1}{2}$	

end of life the whole luminaire shall be replaced The light source of this idilillate is not replaceable, when the light source reacties its

This product contains a light source of energy efficiency class E

E-mail: aftersales@ksrlighting.com KSR Lighting Aftersales: 023 92 674343